



CONNECTOR MAPPING GUIDE

	EFI P/N				GND			B+	IGN							GND			B+	IGN	MIL				
 OBD-II DLC		9	10	11	4,5	14	15	16		8	12	13		1	2	3	4,5	6	7	16					
 BenchForce™ PowerBlock I 24 Pin Gray ECU Header	140-00018	A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1	B12	B11	B10	B9	B8	B7	B6	B5	B4 NO MIL SUPPORT	B3	B2	B1
 BenchForce™ PowerBlock II 24 Pin Gray ECU Header	140-00019	A12	A11	A10	A9	A8 SWITCHABLE	A7	A6	A5	A4	A3	A2	A1	B12	B11	B10	B9	B8 SWITCHABLE	B7	B6	B5	B4 NO MIL SUPPORT	B3	B2	B1
 BenchForce™ PowerBlock III 24 Pin Gray ECU Header	140-00020	A12	A11	A10	A9	A8 SWITCHABLE	A7	A6	A5	A4	A3	A2	A1	B12	B11	B10	B9	B8 SWITCHABLE	B7	B6	B5	B4	B3	B2	B1
 Pass-Through OBD-II (24 Pin BenchForce™)	100-01072					J		B	G					K	H		C	D			E				
 Pass-Through J1939 (24 Pin BenchForce™)	100-01073			K		F	J	B	G					H		E	C	A	D						
 Professional Series Switch 16 Pin Black ECU Header	140-00003	A1	A2	A3	A4	A5	A6	A7	A8	NOT SUPPORTED	NOT SUPPORTED	NOT SUPPORTED		B1	B2	B3	B4	B5	B6	B7	B8	NO MIL SUPPORT			
 Pass-Through for OBD-II (16 Pin Professional Series)	100-01032					J		B	G					K	H		C	D							
 Pass-Through for J1939 (16 Pin Professional Series)	100-01093			K		F	J	B	G					H		E	C	A	D						
 J1939 9 pin DLC Adapter Harness	100-01077			J		D	G	B						E		H	A	C	F						